



Anchor Vista Omni Compact Assembly Guide

Package Content



1x

Anchor Vista Omni
(w/o accessories)



1x

Wall Mount Bracket

Accessories (not included)



1x

Tripod



1x

SmallRig Super
Clamp Mount

1. Assemble the Anchor with a Wall Mount Bracket

1× Anchor Vista Omni
(w/o accessories)



1× Wall Mount Bracket (PN: SWC02-00-00)



Attach the wall mount bracket to the anchor using a Whitworth 1/4" thread.



2. Anchor Deployment using a Tripod

Temporary deployment can be done using tripods. It is a good solution for testing, demos or PoC on the customer's site.

1x SmallRig Super Clamp Mount (bottom & upper part)



1x Tripod (not included)

(Find more details and links for recommended tripods on docs.sewio.net)



Assemble the upper part of the Clamp Mount to the anchor using a Whitworth 1/4" thread.



Mount the anchor on the tripod.





sewio.net

email: info@sewio.net

phone: +420 511 205 215