



sewio.net

email: info@sewio.net

phone: +420 551 205 215

Anchor Vista Omni Compact

Assembly Guide

Package Contains:



1x

Anchor Vista Omni



1x

Wall Mount Bracket

Accessories (not included):



1x

Tripod Adapter 1/2 Screw
Mount
(included in RTLS UWB Kit)



1x

Tripod

1. Assembly Anchor with Wall Mount Bracket

1x Anchor Vista Omni



1x Wall Mount Bracket (PN: SWC02-00-00)



Assembly the wall mount bracket to the anchor via whitworth 1/4" thread



2. Anchor Deployment with Tripod

Temporary deployment can be done with tripods. It is good solution for the testing, demos or PoC on the customer's site.

1x Anchor Vista Omni



1x Tripod Adapter 1/4 Screw Mount (included in RTLS UWB Kit)



1x Tripod (not included)

(For more details and links for recommended tripod on [Sewio Public Docs.](#))



Assembly the tripod adapter to the anchor by whitworth 1/4" thread



Mount the anchor with the adapter on the tripod.

