

Anchor Vista DirectFive Assembly Guide



Package Content



1x
Anchor Vista
DirectFive



1x
RJ45 Feed-thru Lock
Connector



4x
BOSSARD 2000598
/WN 1412



1x
quickMOUNT
PRO LHG

Accessories (not included)



1x
Wall Mount
Metal Bracket

sewio.net

email: info@sewio.net
phone: +420 511 205 215

1. Anchor to Holder

1x Anchor Vista DirectFive



1x quickMOUNT PRO LHG (PN: SWC11-00-00)

quickMount holder package contains screws which **do not fit into Anchor Vista enclosure**, therefore Anchor Vista is delivered with the correct one. Following screws are recommended: PN: **BOSSARD 2000598 or WN 1412**



4x BOSSARD 2000598 or WN 1412




1x RJ45 Feed-thru lock Connector (RCP-00BMMS-TLM7001)



4x BOSSARD 2000598/WN 1412

RJ45 Feed-thru Lock Connector



2. Wall Mount

1x Wall Mount Metal Bracket

Short 15 cm or Long 25 cm

WaveRF PK15I32 (PN: SWC10-02-00)

Metal console for Anchor Vista placement with quickMount PRO LHG holder.



1x Steel Belt



2x Screw with Dowel for Wall Mount

